

Instruction Sheet

B-228 Jacket Ripper Blade



How to Change the Blade on the JR-128

- Remove two screws ① holding the blade ② and remove old blade.
- Insert new blade into slot ③ until holes line up.
- Replace and tighten screws to secure blade.
- Always replace safety cap when not in use.

LIMITED WARRANTY: The JR-128 (Except the Blade) is warranted to be free from defects in workmanship and material for 90 days from date of original purchase.

A SMALL COMPANY WITH BIG IDEAS®



392 PACIFIC STREET
STAMFORD, CT 06902

PHONE: (203) 324-0067 ☆ FAX: (203) 324-7844
www.SeatekCo.com

ese cables. Often the only option for
er & plastic jacketed cables is to use
s is where the Vee-Twin steps in. It is
st, safe to use, and can fit into difficult
itions.

Range
5/16" to 2-1/8" O.D.

**Available
Now!**

strip cables No more stripping
ded knife!

et can strip as many different
use package!



**Perfect to Strip Fiber
Datacom Virtually any**

- Precisely ring & straight cut in one
- Rotating cam that makes it foolpro
- Clever adjustable stop with scale i
same length every time